



National Grid Eastings (metres)

HSE Consultation Zones

Transco, Bethnal Green Holder Station, Marian Place, Bethnal Green, London, E2 9AX

CIS Location 1360
 HSE Ref: #1754
 Grid Ref: TQ 346 834

Prepared - January 2006
 This map supersedes all previous or undated maps

IZ = Inner Zone
 MZ = Middle Zone
 OZ = Outer Zone

